



Kodiak[®] Chiller Overview



Presentation Outline

Lytron Technical Support Contact Information_____	3
Introduction_____	4
Part I: Unpacking_____	5
Part II: Installation_____	7
Part III: Chiller Startup_____	13
Part IV: Flow Components_____	19
Part V: Refrigeration System_____	23
Part VI: Electrical System_____	27
Part VII: Draining and Storage_____	31
Conclusion_____	34

Lytron Technical Support Contact Information

- Lytron is available for technical support 24 hours a day, 7days a week.

- To contact us, please call 781-933-7300
 - When calling after hours, please select the “System Service Group” option to be connected to our on-call Service Engineer


Introduction

- This program is designed to train Kodiak chiller users.
- Topics covered include: unpacking, installation, the basic control functions and all the internal components of a Lytron Kodiak Chiller.
- The chiller models discussed in this presentation are the Kodiak RC006G03 through RC045H03 as they are presently manufactured.
- Always turn the unit "OFF" and disconnect the power cord from the power source before performing any service or maintenance procedures, or before moving the unit.

Part I: Unpacking

- Carefully unpack the chiller and check for shipping damage. If you notice shipping damage, immediately contact your freight carrier. Please note that Lytron is not responsible for any shipping damage.
- Save the packaging for any future shipping. If the chiller ever needs to be shipped to another location, or in the unlikely event that the chiller needs to be returned to Lytron, we recommend that you use the original packaging.

Part I: Unpacking - Chiller nameplate



- Confirm that the chiller you received is the correct one by checking the model and serial number found on the nameplate, on the rear of the unit.
- Verify the chiller's power requirements and make sure that it has the proper electrical configuration for your facility's power supply.